PID/DATA MONITOR TABLE [DSC HU/CM]

id040262886400

Note

- If the PID “STR_ANG_R” is inspected, perform the following procedure before inspecting.
  1. Switch the ignition to OFF, and maintain this condition for **approx. 3 s**.
  2. Set the vehicle wheels in the straight-ahead position.
  3. Switch the ignition ON (engine off or on).

Monitor item M-MDS display	Unit/ Operation	Test condition	Specification (Reference)	Inspection item
BRAKE_SW	Off/On	Brake pedal released	Off	• Inspect the brake switch. (See BRAKE SWITCH INSPECTION.)
		Brake pedal depressed	On	
BRK_F_P_C	Pa, psi	Brake pedal depressed	Changes according to the brake fluid pressure	• Inspect the brake fluid pressure sensor. (See BRAKE FLUID PRESSURE SENSOR INSPECTION.)
BRK_F_P_R	Pa, psi	Brake pedal depressed	Changes according to the brake fluid pressure	• Inspect the brake fluid pressure sensor. (See BRAKE FLUID PRESSURE SENSOR INSPECTION.)
DDS_MODE	Not_Learned/Learning/Learned	During initialization	Not_Learned	• Perform the DTC inspection for the DSC HU/CM. (See DTC INSPECTION [DSC HU/CM].)
		During learning	Learning	
		Learning completed*	Learned	
DSC_OFF_SW	Off/On	DSC OFF switch is released	Off	• Inspect the DSC OFF switch. (See DSC OFF SWITCH INSPECTION.)
		DSC OFF switch is depressed	On	
DSC_ST	Off/On	During DSC OFF mode	Off	• Perform the DTC inspection for the DSC HU/CM. (See DTC INSPECTION [DSC HU/CM].)
		Other than DSC OFF mode	On	
LAT_ACCL_C (calculated value)	G	Vehicle stopped or driving at constant speed	0 G	• Perform the DTC inspection for the SAS control module. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See DTC INSPECTION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
		Cornering to left	Changes to 0 G—positive	
		Cornering to right	Changes to 0 G—negative	
LAT_ACCL_R (raw value)	G	Vehicle stopped or driving at constant speed	0 G	• Perform the DTC inspection for the SAS control module. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See DTC INSPECTION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
		Cornering to left	Changes to 0 G—positive	
		Cornering to right	Changes to 0 G—negative	
LON_ACCL_C (calculated value)	G	Vehicle stopped or driving at constant speed	0 G	• Perform the DTC inspection for the SAS control module. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See DTC INSPECTION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
		Cornering to left	Changes to 0 G—positive	
		Cornering to right	Changes to 0 G—negative	

Monitor item M-MDS display	Unit/ Operation	Test condition	Specification (Reference)	Inspection item
LON_ACCL_R (raw value)	G	Vehicle stopped or driving at constant speed	0 G	• Perform the DTC inspection for the SAS control module. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See DTC INSPECTION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
		Cornering to left	Changes to 0 G—positive	
		Cornering to right	Changes to 0 G—negative	
P_BRAKE_SW	Off/On	Parking brake lever released	Off	• Inspect the parking brake switch. (See PARKING BRAKE SWITCH INSPECTION.)
		Parking brake lever pulled	On	
PMP_MT PMP_MT_SP	**Note** • Displays in the M-MDS but it does not operate.			
R_GEAR_SW	Off/On	Except shift/selector lever at R position	Off	• Perform the DTC inspection for the PCM. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Perform the DTC inspection for the TCM. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (CW6A-EL)].) (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (EW6A-EL)].)
		Shift/selector lever at R position	On	

Monitor item M-MDS display	Unit/ Operation	Test condition	Specification (Reference)	Inspection item
STR_ANG_C (calculated value) **Note** • Constantly indicates 0 ° until the steering wheel angle neutral position determination by the DSC HU/CM is completed. • The steering wheel angle neutral position determination by the DSC HU/CM is completed when the vehicle is driven in a straight line at a speed of 20 km/h {12 mph} or more for several seconds.	°	Steering wheel in neutral position	0 °	• Perform the DTC inspection for the PCM, DSC HU/CM, and EPS control module. If a DTC is displayed after performing the DTC inspection for the PCM, DSC HU/CM, and EPS control module, repair the malfunctioning part according to the applicable DTC troubleshooting. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) (See DTC INSPECTION [DSC HU/CM].) (See DTC INSPECTION [EPS CONTROL MODULE].) • After performing the DTC inspection, perform the following procedure: – Start the engine and drive the vehicle in a straight line at a speed of 20 km/h {12 mph} or more for several seconds. • If an abnormal value is indicated after verifying the value of the STR_ANG_C again, replace the DSC HU/CM. (See DSC HU/CM REMOVAL/INSTALLATION [L.H.D.].) (See DSC HU/CM REMOVAL/INSTALLATION [R.H.D.].)
		Steered left	Changes to 0 °—positive	
		Steered right	Changes to 0 °—negative	
STR_ANG_R (raw value) **Note** • The signal indicated in this item is a steering angle (relative angle) in the EPS control module.	°	Steering wheel position when ignition is switched ON (engine off or on)	0 °	• Inspect the following PID: (See PID/DATA MONITOR TABLE [EPS CONTROL MODULE].) – STR_ANG (EPS control module)
		Steered left	Changes to 0 °—positive	
		Steered right	Changes to 0 °—negative	
TPMS_TYPE	No_DDS/ DDS/DDS +TOM_O/ DDS +TOM_EU/ DDS +TOM_US	Tire Pressure Monitoring System (TPMS) not equipped	No_DDS	—
		Tire Pressure Monitoring System (TPMS) equipped (corresponding to regulation)	DS +TOM_O/ DDS +TOM_EU/ DDS +TOM_US	
V_INLET_LF	Off/On	Solenoid valve not activated	Off	• Inspect the DSC HU/CM. (See DSC HU/CM INSPECTION.)
		Solenoid valve activated	On	

Monitor item M-MDS display	Unit/ Operation	Test condition	Specification (Reference)	Inspection item
V_INLET_LR	Off/On	Solenoid valve not activated	Off	• Inspect the DSC HU/CM. (See DSC HU/CM INSPECTION.)
		Solenoid valve activated	On	
V_INLET_RF	Off/On	Solenoid valve not activated	Off	• Inspect the DSC HU/CM. (See DSC HU/CM INSPECTION.)
		Solenoid valve activated	On	
V_INLET_RR	Off/On	Solenoid valve not activated	Off	• Inspect the DSC HU/CM. (See DSC HU/CM INSPECTION.)
		Solenoid valve activated	On	
V_OUTLET_LF	Off/On	Solenoid valve not activated	Off	• Inspect the DSC HU/CM. (See DSC HU/CM INSPECTION.)
		Solenoid valve activated	On	
V_OUTLET_LR	Off/On	Solenoid valve not activated	Off	• Inspect the DSC HU/CM. (See DSC HU/CM INSPECTION.)
		Solenoid valve activated	On	
V_OUTLET_RF	Off/On	Solenoid valve not activated	Off	• Inspect the DSC HU/CM. (See DSC HU/CM INSPECTION.)
		Solenoid valve activated	On	
V_OUTLET_RR	Off/On	Solenoid valve not activated	Off	• Inspect the DSC HU/CM. (See DSC HU/CM INSPECTION.)
		Solenoid valve activated	On	
V_STB_LF/RR V_STB_RF/LR	**Note** • Displays in the M-MDS but it does not operate.			
V_TRC_LF/RR V_TRC_RF/LR	**Note** • Displays in the M-MDS but it does not operate.			
V_TRC_RF/LR	Off/On	Solenoid valve not activated	Off	• Inspect the DSC HU/CM. (See DSC HU/CM INSPECTION.)
		Solenoid valve activated	On	
VPWR_B_SOL	V	This PID indicates power supply voltage for DSC HU/CM.		• Inspect the DSC HU/CM. (See DSC HU/CM INSPECTION.)
VSPD	KPH, MPH	This PID indicates vehicle speed.		• Inspect the DSC HU/CM. (See DSC HU/CM INSPECTION.)
WSPD_SEN_LF	KPH, MPH	This PID indicates vehicle speed.		• Inspect the LF ABS wheel-speed sensor. (See FRONT ABS WHEEL-SPEED SENSOR INSPECTION.)
WSPD_SEN_LR	KPH, MPH	This PID indicates vehicle speed.		• Inspect the LR ABS wheel-speed sensor. (See REAR ABS WHEEL-SPEED SENSOR INSPECTION.)
WSPD_SEN_RF	KPH, MPH	This PID indicates vehicle speed.		• Inspect the RF ABS wheel-speed sensor. (See FRONT ABS WHEEL-SPEED SENSOR INSPECTION.)
WSPD_SEN_RR	KPH, MPH	This PID indicates vehicle speed.		• Inspect the RR ABS wheel-speed sensor. (See REAR ABS WHEEL-SPEED SENSOR INSPECTION.)

Monitor item M-MDS display	Unit/ Operation	Test condition	Specification (Reference)	Inspection item
YAW_RATE_C (calculated value)	°/s	Vehicle stopped or driving at constant speed	0 °/s	• Perform the DTC inspection for the SAS control module. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See DTC INSPECTION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
		Cornering to left	Changes to 0 °/s—positive	
		Cornering to right	Changes to 0 °/s—negative	
YAW_RATE_R (raw value)	°/s	Vehicle stopped or driving at constant speed	0 °/s	• Perform the DTC inspection for the SAS control module. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See DTC INSPECTION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
		Cornering to left	Changes to 0 °/s—positive	
		Cornering to right	Changes to 0 °/s—negative	