DTC C0062:76 [DSC HU/CM]

id040262901000

DTC	C0062:76	SAS control module
DETECTION CONDITION		• Communication error to SAS control module is detected in CAN communication
FAIL-SAFE FUNCTION		Refer to DTC TABLE. (See DTC TABLE [DSC HU/CM].)
POSSIBLE CAUSE		• Poor SAS control module installation • Low-G sensor malfunction in SAS control module
SYSTEM WIRING DIAGRAM		—

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY IF SAS CONTROL MODULE IS CORRECTLY INSTALLED** • Verify the SAS control module installation condition. • Is the installation condition normal?	Yes	Go to the next step.
		No	Install the SAS control module correctly, then go to the next step.
2	**VERIFY SAS CONTROL MODULE DTC** • Using the M-MDS, perform the SAS control module DTC inspection. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See DTC INSPECTION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See DTC TABLE [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) DTC troubleshooting completed, then go to the next step.
		No	Go to the next step.
3	**PERFORM DSC RELATED PARTS SENSOR INITIALIZATION PROCEDURE** • Using the M-MDS, perform the DSC related parts sensor initialization procedure. (See DSC RELATED PARTS SENSOR INITIALIZATION PROCEDURE.) — Lateral acceleration sensor (low-G sensor) — Longitudinal acceleration sensor (low-G sensor) — Yaw rate sensor • Is the DSC sensor initialization procedure completed normally?	Yes	Go to the next step.
		No	Replace the DSC HU/CM, then go to the next step. (See DSC HU/CM REMOVAL/INSTALLATION [L.H.D.].) (See DSC HU/CM REMOVAL/INSTALLATION [R.H.D.].)
4	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Using the M-MDS, clear the DTC from the DSC HU/CM. (See CLEARING DTC [DSC HU/CM].) • Using the M-MDS, perform the DSC HU/CM DTC inspection. (See DTC INSPECTION [DSC HU/CM].) • Is the same DTC present?	Yes	Repeat the inspection from Step1 If the malfunction recurs, replace the DSC HU/CM, then go to the next step. (See DSC HU/CM REMOVAL/INSTALLATION [L.H.D.].) (See DSC HU/CM REMOVAL/INSTALLATION [R.H.D.].)
		No	Go to the next step.
5	**VERIFY NO DTC IS PRESENT** • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [DSC HU/CM].)
		No	DTC troubleshooting completed.