DTC C0061:54/C0062:54/C0063:54 [DSC HU/CM]

id040262901200

DTC	**C0061:54** **C0062:54** **C0063:54**	**DSC HU/CM (unperformed initialization procedure)**
DETECTION CONDITION		• C0061:54, C0062:54 — DSC HU/CM detects that the initialization procedure has not been performed • C0063:54 — DSC HU/CM detects that the initialization procedure has not been performed
FAIL-SAFE FUNCTION		Refer to DTC TABLE. (See DTC TABLE [DSC HU/CM].)
POSSIBLE CAUSE		• Initialization procedure for the DSC related parts sensor not performed — Low-G sensor — Yaw rate sensor • SAS control module malfunction • DSC HU/CM malfunction
SYSTEM WIRING DIAGRAM		—

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY INITIALIZATION PROCEDURE** • Was the following DSC related parts sensor initialization procedure performed? — Lateral acceleration sensor (low-G sensor) — Longitudinal acceleration sensor (low-G sensor) — Yaw rate sensor	Yes	Go to the next step.
		No	Perform the DSC related parts sensor initialization procedure, then go to Step3. (See DSC RELATED PARTS SENSOR INITIALIZATION PROCEDURE.)
2	**VERIFY SAS CONTROL MODULE DTC** • Using the M-MDS, perform the SAS control module DTC inspection. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See DTC INSPECTION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See DTC TABLE [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) DTC troubleshooting completed, then go to the next step.
		No	Go to the next step.
3	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Using the M-MDS, clear the DTC from the DSC HU/CM. (See CLEARING DTC [DSC HU/CM].) • Using the M-MDS, perform the DSC HU/CM DTC inspection. (See DTC INSPECTION [DSC HU/CM].) • Is the same DTC present?	Yes	Repeat the inspection from Step1 If the malfunction recurs, replace the DSC HU/CM, then go to the next step. (See DSC HU/CM REMOVAL/INSTALLATION [L.H.D.].) (See DSC HU/CM REMOVAL/INSTALLATION [R.H.D.].)
		No	Go to the next step.
4	**VERIFY NO DTC IS PRESENT** • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [DSC HU/CM].)
		No	DTC troubleshooting completed.