DTC U0433:00 [DSC HU/CM]

id040262905400

DTC	U0433:00	Signal error from laser sensor
DETECTION CONDITION		• Error detected in signal from laser sensor via CAN communication
FAIL-SAFE FUNCTION		Refer to DTC TABLE. (See DTC TABLE [DSC HU/CM].)
POSSIBLE CAUSE		• Laser sensor malfunction
SYSTEM WIRING DIAGRAM		—

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY PCM DTC** • Using the M-MDS, perform the laser sensor DTC inspection. (See DTC INSPECTION [LASER SENSOR].) • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [LASER SENSOR].) DTC troubleshooting completed, then go to the next step.
		No	Go to the next step.
2	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Using the M-MDS, clear the DTC from the DSC HU/CM. (See CLEARING DTC [DSC HU/CM].) • Using the M-MDS, perform the DSC HU/CM DTC inspection. (See DTC INSPECTION [DSC HU/CM].) • Is the same DTC present?	Yes	Repeat the inspection from Step1 If the malfunction recurs, replace the laser sensor, then go to the next step. (See LASER SENSOR REMOVAL/INSTALLATION.)
		No	Go to the next step.
3	**VERIFY NO DTC IS PRESENT** • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [DSC HU/CM].)
		No	DTC troubleshooting completed.