DTC B10DF:46/C1A08:1C/U2007:46/U2007:62/U3000:49 [DSC HU/CM]

id040262905700

DTC	B10DF:46	DSC HU/CM internal malfunction
	C1A08:1C	
	U2007:46	
	U2007:62	
	U3000:49	
DETECTION CONDITION		• Malfunction detected by self-diagnosis program of DSC HU/CM
FAIL-SAFE FUNCTION		Refer to DTC TABLE. (See DTC TABLE [DSC HU/CM].)
POSSIBLE CAUSE		• DSC HU/CM internal malfunction
SYSTEM WIRING DIAGRAM		—

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY DSC HU/CM DTC** • Using the M-MDS, clear the DTC from the DSC HU/CM. (See CLEARING DTC [DSC HU/CM].) • Start the engine and drive the vehicle at 10 km/h {6.2 mph} or more. • Using the M-MDS, perform the DSC HU/CM DTC inspection. (See DTC INSPECTION [DSC HU/CM].) • Are any DTCs present?	Yes	Replace the DSC HU/CM, then go to the next step. (See DSC HU/CM REMOVAL/INSTALLATION [L.H.D.].) (See DSC HU/CM REMOVAL/INSTALLATION [R.H.D.].)
		No	Go to the next step.
2	**VERIFY NO DTC IS PRESENT** • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [DSC HU/CM].)
		No	DTC troubleshooting completed.