## DTC C1031:68 [DSC HU/CM]

id040262907000

| DTC | C1031:68 | Tire Pressure Monitoring System (TPMS) |
|---|---|---|
| DETECTION CONDITION | | • Error is detected in ambient temperature sensor from PCM via CAN communication |
| FAIL-SAFE FUNCTION | | Refer to DTC TABLE. (See DTC TABLE [DSC HU/CM].) |
| POSSIBLE CAUSE | | • Ambient temperature sensor malfunction<br>• PCM malfunction |
| SYSTEM WIRING DIAGRAM | | — |

### Diagnostic Procedure

| Step | Inspection | | Action |
|---|---|---|---|
| 1 | **VERIFY PCM DTC**<br>• Using the M-MDS, perform the PCM DTC inspection.<br>(See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)<br>(See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].)<br>• Are any DTCs present? | Yes | Go to applicable DTC inspection.<br>(See DTC TABLE [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)<br>(See DTC TABLE [SKYACTIV-D 1.5].)<br>DTC troubleshooting completed, then go to the next step. |
| | | No | Go to the next step. |
| 2 | **INSPECT AMBIENT TEMPERATURE SENSOR**<br>• Inspect the ambient temperature sensor.<br>(See AMBIENT TEMPERATURE SENSOR INSPECTION [MANUAL AIR CONDITIONER].)<br>(See AMBIENT TEMPERATURE SENSOR INSPECTION [FULL-AUTO AIR CONDITIONER].)<br>• Is the ambient temperature sensor normal? | Yes | Go to the next step. |
| | | No | Replace the ambient temperature sensor, then go to the next step.<br>(See AMBIENT TEMPERATURE SENSOR REMOVAL/INSTALLATION [MANUAL AIR CONDITIONER].)<br>(See AMBIENT TEMPERATURE SENSOR REMOVAL/INSTALLATION [FULL-AUTO AIR CONDITIONER].) |
| 3 | **VERIFY DTC TROUBLESHOOTING COMPLETED**<br>• Using the M-MDS, clear the DTC from the DSC HU/CM.<br>(See CLEARING DTC [DSC HU/CM].)<br>• Using the M-MDS, perform the DSC HU/CM DTC inspection.<br>(See DTC INSPECTION [DSC HU/CM].)<br>• Is the same DTC present? | Yes | Repeat the inspection from Step1<br>If the malfunction recurs, replace the PCM, then go to the next step.<br>(See PCM REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)<br>(See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) |
| | | No | Go to the next step. |
| 4 | **VERIFY NO DTC IS PRESENT**<br>• Are any DTCs present? | Yes | Go to applicable DTC inspection.<br>(See DTC TABLE [DSC HU/CM].) |
| | | No | DTC troubleshooting completed. |