DTC U2300:54/U2300:55/U2300:56/U2300:64 [LASER SENSOR]

id0402c4855400

DTC	**U2300:54**	**Laser sensor configuration**
	U2300:55	
	U2300:56	
	U2300:64	
DETECTION CONDITION		• Laser sensor detects configuration data not recorded or data error
FAIL-SAFE FUNCTION		• Smart City Brake Support (SCBS) warning light (amber) Illuminates • Smart City Brake Support (SCBS) control disabled
POSSIBLE CAUSE		• Configuration procedure is not done properly • Correct data cannot be received from instrument cluster
SYSTEM WIRING DIAGRAM		—

Diagnostic Procedure

Step	Inspection		Action
1	**RECORD CONFIGURATION DATA** • Switch the ignition to OFF. • Switch the ignition ON (engine off).		Go to the next step.
2	**VERIFY LASER SENSOR DTC** • Using the M-MDS, clear the DTC from the laser sensor. (See CLEARING DTC [LASER SENSOR].) • Using the M-MDS, perform the laser sensor DTC inspection. (See DTC INSPECTION [LASER SENSOR].) • Is the same DTC present?	Yes	Repeat the inspection from Step1. If the malfunction recurs, go to the next step.
		No	Go to Step6.
3	**VERIFY IF PARTS FROM ANOTHER VEHICLE INSTALLED TO INSTRUMENT CLUSTER OR PCM** • Verify if an instrument cluster or PCM from another vehicle is installed. • Has an instrument cluster, PCM or other vehicle part been installed to vehicle?	Yes	Install the correct instrument cluster or PCM, then go to Step1. (See INSTRUMENT CLUSTER REMOVAL/INSTALLATION.) (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
		No	Go to the next step.
4	**VERIFY INSTRUMENT CLUSTER AND PCM DTC** • Using the M-MDS, perform the instrument cluster and PCM DTC inspection. (See DTC INSPECTION [INSTRUMENT CLUSTER].) (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER].) (See DTC TABLE [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See DTC TABLE [SKYACTIV-D 1.5].) DTC troubleshooting completed, then go to the next step.
		No	Go to the next step.
5	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Using the M-MDS, clear the DTC from the laser sensor. (See CLEARING DTC [LASER SENSOR].) • Using the M-MDS, perform the laser sensor DTC inspection. (See DTC INSPECTION [LASER SENSOR].) • Is the same DTC present?	Yes	Repeat the inspection from Step1. If the malfunction recurs, replace the laser sensor, then go to the next step. (See LASER SENSOR REMOVAL/INSTALLATION.)
		No	Go to the next step.
6	**VERIFY NO DTC IS PRESENT** • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [LASER SENSOR].)
		No	DTC troubleshooting completed.