PID/DATA MONITOR TABLE [LASER SENSOR]

id0402c4886400

Monitor item M-MDS display	Unit/ Operation	Test condition	Specification (Reference)	Inspection item
DST_BMP_TGT	m, ft	This PID indicates distance from front bumper to target that laser sensor has detected.		• Replace the laser sensor, windshield. (See LASER SENSOR REMOVAL/INSTALLATION.) (See WINDSHIELD REMOVAL.) (See WINDSHIELD INSTALLATION.)
VPWR_IG1	V	This PID indicates power supply voltage for laser sensor.		• Inspect the battery. (See BATTERY INSPECTION.) • Inspect power supply circuit (ignition switch, IG1 relay, fuse etc.) (See PUSH BUTTON START REMOVAL/INSTALLATION.) (See RELAY INSPECTION.)
VSPD	KPH, MPH	This PID indicates vehicle speed.		• Inspect the DSC HU/CM. (See DSC HU/CM INSPECTION.)