DTC U1A14:49 [LASER SENSOR]

id0402c4894700

DTC	U1A14:49	Laser sensor
DETECTION CONDITION		• Electronic malfunction detected by self-diagnosis program of laser sensor when the ignition is switched ON
FAIL-SAFE FUNCTION		• Smart City Brake Support (SCBS) warning light (amber) Illuminates • Smart City Brake Support (SCBS) control disabled
POSSIBLE CAUSE		• Laser sensor malfunction
SYSTEM WIRING DIAGRAM		—

Diagnostic Procedure

Step	Inspection		Action
1	**RECORD CONFIGURATION DATA** • Switch the ignition to OFF. • Switch the ignition ON (engine off).		Go to the next step.
2	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Using the M-MDS, clear the DTC from the laser sensor. (See CLEARING DTC [LASER SENSOR].) • Using the M-MDS, perform the laser sensor DTC inspection. (See DTC INSPECTION [LASER SENSOR].) • Is the same DTC present?	Yes	Repeat the inspection from Step1. If the malfunction recurs, replace the laser sensor, then go to the next step. (See LASER SENSOR REMOVAL/INSTALLATION.)
		No	Go to the next step.
3	**VERIFY NO DTC IS PRESENT** • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [LASER SENSOR].)
		No	DTC troubleshooting completed.