SYMPTOM TROUBLESHOOTING [DYNAMIC STABILITY CONTROL (DSC)]

id0403b2804200

- Verify the symptoms, and perform troubleshooting according to the appropriate number.

No.	Symptom
1	Any of the following lights are not illuminated when the ignition is switched ON: • ABS warning light • Brake system warning light • TCS/DSC indicator light • DSC OFF indicator light
2	Any of the following lights remain illuminated: • ABS warning light • TCS/DSC indicator light • DSC OFF indicator light
3	Brake system warning light remains illuminated
4	A malfunction in the system even though the ABS warning light, brake system warning light, TCS/DSC indicator light and DSC OFF indicator light are not illuminated
5	ABS or TCS*1 operates frequently
	TCS does not work correctly
6	DSC*2 operates frequently
	DSC does not work correctly
7	Hill launch assist (HLA) operates even on a down slope
	Hill launch assist (HLA) does not operate on a slope
8	Smart city brake support (SCBS) warning light (amber) turns on and message indicating Smart City Brake Support (SCBS) malfunction is displayed in center display

X: Applied

Troubleshooting item	1	2	3	4	5	6	7	8
	Any of the following lights are not illuminated with the ignition switched ON: (ABS warning light, brake system warning light, TCS/DSC indicator light and/or DSC OFF indicator light)	Any of the following lights remain illuminated: (ABS warning light, TCS/DSC indicator light and/or DSC OFF indicator light)	Brake system warning light remains illuminated	A malfunction in the system even though the ABS warning light, brake system warning light, TCS/DSC indicator light and DSC OFF indicator light are not illuminated	ABS or TCS*1 operates frequently TCS does not work correctly *1: DSC system function contains traction control function, TCS/DSC indicator light turns on and off while TCS operates	DSC*2 operates frequently DSC does not work correctly *2: TCS/DSC indicator light turns on and off while DSC operates	Hill launch assist (HLA) operates even on a down slope Hill launch assist (HLA) does not operate on a slope	Smart Brake Support/Smart City Brake Support (SBS/SCBS) indicator light (amber) stay on
DSC HU/CM does not operate	X	X	X					
Communication error between DSC HU/CM and instrument cluster	X	X					X	
Instrument cluster malfunction	X		X				X	X
DSC HU/CM internal malfunction	X							

Troubleshooting item	1	2	3	4	5	6	7	8
	Any of the following lights are not illuminated with the ignition switched ON: (ABS warning light, brake system warning light, TCS/DSC indicator light and/or DSC OFF indicator light)	Any of the following lights remain illuminated: (ABS warning light, TCS/DSC indicator light and/or DSC OFF indicator light)	Brake system warning light remains illuminated	A malfunction in the system even though the ABS warning light, brake system warning light, TCS/DSC indicator light and DSC OFF indicator light are not illuminated	ABS or TCS*1 operates frequently TCS does not work correctly *1: DSC system function contains traction control function, TCS/DSC indicator light turns on and off while TCS operates	DSC*2 operates frequently DSC does not work correctly *2: TCS/DSC indicator light turns on and off while DSC operates	Hill launch assist (HLA) operates even on a down slope Hill launch assist (HLA) does not operate on a slope	Smart Brake Support/Smart City Brake Support (SBS/SCBS) indicator light (amber) stay on
No connection at DSC HU/CM		X	X					
DSC HU/CM detected malfunction (input and output device malfunction).		X	X			X	X	X
DSC HU/CM detected low voltage in power supply		X	X					
DSC HU/CM ground malfunction		X	X					
PCM detected malfunction		X					X	X
Communication error between DSC HU/CM and PCM		X					X	
Communication error between DSC HU/CM and EPS control module		X						
After replacing DSC HU/CM and SAS control module , the DSC related parts sensor initialization has not been performed		X				X	X	
Non-completion of module configuration		X						
Parking brake switch signal error input to instrument cluster			X					
Brake fluid level sensor signal error input to body control module (BCM)			X					
Brake fluid amount is low			X					
Parking brake does not release			X					
Mechanical malfunction in system				X				
Difference in size, condition or air pressure between front and rear tires					X	X		
Incorrect ABS wheel-speed signal is input to DSC HU/CM					X		X	

Troubleshooting item	1 Any of the following lights are not illuminated with the ignition switched ON: (ABS warning light, brake system warning light, TCS/DSC indicator light and/or DSC OFF indicator light)	2 Any of the following lights remain illuminated: (ABS warning light, TCS/DSC indicator light and/or DSC OFF indicator light)	3 Brake system warning light remains illuminated	4 A malfunction in the system even though the ABS warning light, brake system warning light, TCS/DSC indicator light and DSC OFF indicator light are not illuminated	5 ABS or TCS*1 operates frequently TCS does not work correctly *1: DSC system function contains traction control function, TCS/DSC indicator light turns on and off while TCS operates	6 DSC*2 operates frequently DSC does not work correctly *2: TCS/DSC indicator light turns on and off while DSC operates	7 Hill launch assist (HLA) operates even on a down slope Hill launch assist (HLA) does not operate on a slope	8 Smart Brake Support/Smart City Brake Support (SBS/SCBS) indicator light (amber) stay on
Malfunction in engine control system (TCS malfunction)					X			
Poor installation with SAS control module (yaw rate sensor, low-G sensor)						X	X	
Center point of low-G sensor has deviated							X	
Input signal malfunction from PCM							X	
Input signal malfunction from instrument cluster							X	
Input signal malfunction from TCM							X	
Brake (foot brake/parking brake drag)							X	
Laser sensor internal malfunction								

*1 : DSC system function contains traction control function, TCS/DSC indicator light turns on and off while TCS operates

*2 : TCS/DSC indicator light turns on and off while DSC operates