NO.4 A MALFUNCTION IN THE SYSTEM EVEN THOUGH THE ABS WARNING LIGHT, BRAKE SYSTEM WARNING LIGHT, TCS/DSC INDICATOR LIGHT AND DSC OFF INDICATOR LIGHT ARE NOT ILLUMINATED [DYNAMIC STABILITY CONTROL (DSC)]

id0403b2897200

4	**A malfunction in the system even though the ABS warning light, brake system warning light, TCS/ DSC indicator light and DSC OFF indicator light are not illuminated**
POSSIBLE CAUSE	• Mechanical malfunction in system.

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**CONFIRM DSC HU/CM DTC** • Retrieve the DSC HU/CM DTC using the M-MDS. (See DTC INSPECTION [DSC HU/CM].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC INSPECTION [DSC HU/CM].)
		No	Go to the next step.
2	**VERIFY SOLENOID VALVE AND PUMP MOTOR OPERATION** • Switch the ignition off. • Connect the M-MDS to the DLC-2. • Switch the ignition ON (engine off). • Access the active command mode for the solenoid valve and pump motor using the M-MDS. (See DTC INSPECTION [DSC HU/CM].) • Do the solenoid valve and pump motor operate?	Yes	Inspect the conventional brake system. If there is a malfunction: • Repair or replace any malfunctioning parts according to the inspection result.
		No	Repair or replace any malfunctioning parts according to the inspection result.