NO.6 DSC*2 OPERATES FREQUENTLY/DSC DOES NOT WORK CORRECTLY *2: TCS/DSC INDICATOR LIGHT TURNS ON AND OFF WHILE DSC OPERATES [DYNAMIC STABILITY CONTROL (DSC)]

id0403b2897600

6	**DSC*2 operates frequently** **DSC does not work correctly** ***2: TCS/DSC indicator light turns on and off while DSC operates**
POSSIBLE CAUSE	• DSC HU/CM detected malfunction. (Input and output device malfunction) • Poor installation with SAS control module (yaw rate sensor, low-G sensor) (If SAS control module is poorly installed, DSC may operate intermittently.) • There is a difference in condition or air pressure between front or rear tires. • When replacing DSC HU/CM and SAS control module, initialization is not performed. (If initialization is not performed correctly, DSC may not work correctly.)

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**CONFIRM DSC HU/CM DTC** • Retrieve the DSC HU/CM DTC using the M-MDS. (See DTC INSPECTION [DSC HU/CM].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC INSPECTION [DSC HU/CM].)
		No	Go to the next step.
2	**CONFIRM LASER SENSOR DTC** • Retrieve the laser sensor DTC using the M-MDS. (See DTC INSPECTION [LASER SENSOR].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [LASER SENSOR].)
		No	Go to the next step.
3	**VERIFY THAT BRAKE FLUID PRESSURE SENSOR IS INITIALIZED** • Verify that each sensor is initialized. • Has the initialization for the DSC HU/CM been performed after replacing the DSC HU/CM and the SAS control module?	Yes	Inspect the tire pressure and condition. **If the tire pressure is incorrect:** • Adjust the tire pressure to the specification **If the tires are worn:** • Replace the tires. **If the tire pressure and condition is normal:** • Found malfunctioning part according to the “INTERMITTENT CONCERN TROUBLESHOOTING”. (See PRECAUTION [DYNAMIC STABILITY CONTROL (DSC)].)
		No	Perform the initialization procedure. (See DSC RELATED PARTS SENSOR INITIALIZATION PROCEDURE.)