ABS WHEEL-SPEED SENSOR AND ABS SENSOR ROTOR

id041500104900

Purpose/Function

- The ABS wheel-speed sensor detects and transmits the rotation condition of each wheel to the DSC HU/CM.
- The signal from the ABS wheel-speed sensors is the primary signal for DSC HU/CM control.

Construction/Operation

- The construction and operation of the ABS wheel-speed sensor is the same as that of vehicles with ABS.

Fail-safe

DTC No.	Fail-safe function
C0030:07	• Illuminates the ABS warning light, TCS/DSC indicator light, and Smart City Brake Support (SCBS) warning light (amber)*. • Tire pressure monitoring system warning light illuminates after flashes*. • Inhibits the ABS, TCS, DSC, brake assist control, vehicle roll prevention function*, Hill Launch Assist (HLA), TPMS*, Secondary Collision Reduction (SCR)*, and Smart City Brake Support (SCBS)* controls. (Additionally, when any malfunction is detected in two wheels or more, EBD control is inhibited and the brake system warning light is illuminated.) *: If equipped.
C0031:07	
C0031:11	
C0031:15	
C0031:29	
C0031:2F	
C0031:64	
C0033:07	
C0034:07	
C0034:11	
C0034:15	
C0034:29	
C0034:2F	
C0034:64	
C0036:07	
C0037:07	
C0037:11	
C0037:15	
C0037:29	
C0037:2F	
C0037:64	
C0039:07	
C003A:07	
C003A:11	
C003A:15	
C003A:29	
C003A:2F	
C003A:64	