BRAKE FLUID PRESSURE SENSOR

id041500105200

Purpose/Function

- The brake fluid pressure sensor detects the fluid pressure from the master cylinder and transmits it to the DSC HU/CM.

Construction

- The brake fluid pressure sensor is built into the DSC HU/CM. Therefore, if there is any malfunction of the brake fluid pressure sensor, replace the DSC HU/CM.

Fail-safe

DTC No.	Fail-safe function
C0044:28 C0044:47 C0044:49 C0044:51	• Illuminates the TCS/DSC indicator light, and Smart City Brake Support (SCBS) warning light (amber)*1*2. • Tire pressure monitoring system warning light*1 illuminates after flashes. (Not illuminated/flashed depending on malfunction content.) • Inhibits the TCS*3, DSC*3, brake assist control, vehicle roll prevention function*1*3, Hill Launch Assist (HLA)*3, TPMS*1*3, Secondary Collision Reduction (SCR)*1*3, and Smart City Brake Support (SCBS)*1*3 controls. *1: If equipped. *2: Not illuminated depending on malfunction content. *3: Enabled depending on malfunction content.
C0044:54	• Illuminates the TCS/DSC indicator light, and Smart City Brake Support (SCBS) warning light (amber)*1. • Tire pressure monitoring system warning light*1 illuminates after flashes. (Not illuminated/flashed depending on malfunction content.) • Inhibits the TCS, DSC, brake assist control, vehicle roll prevention function*1, Hill Launch Assist (HLA), TPMS*1*3, Secondary Collision Reduction (SCR)*1, and Smart City Brake Support (SCBS)*1 controls. *1: If equipped. *2: Not illuminated depending on malfunction content. *3: Enabled depending on malfunction content.

DTC No.	Fail-safe function
C0044:64 C0044:8F	• Illuminates the TCS/DSC indicator light, and Smart City Brake Support (SCBS) warning light (amber)*1. • Tire pressure monitoring system warning light*1 illuminates after flashes. • Inhibits the TCS, DSC, brake assist control, vehicle roll prevention function*1, Hill Launch Assist (HLA), TPMS*1, Secondary Collision Reduction (SCR)*1, and Smart City Brake Support (SCBS)*1 controls. *1: If equipped.