DTC P1738:00 [TCM (CW6A-EL)]

id0502p4578400

DTC P1738:00	Automatic transaxle internal malfunction
DETECTION CONDITION	• Malfunction location cannot be determined based on combination of gear ratio malfunction and oil pressure switch pattern malfunction.
FAIL-SAFE FUNCTION	• Inhibits learning control. • Inhibits manual mode. • Inhibits i-stop control. • Inhibits AAS.
POSSIBLE CAUSE	• ATF is less than specified value • Automatic transaxle internal malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**INSPECT ATF LEVEL** • Inspect the ATF level. (See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [CW6A-EL].) • Is there any malfunction?	Yes	Adjust the ATF level to the specification, then go to the next step. (See AUTOMATIC TRANSAXLE FLUID (ATF) ADJUSTMENT [CW6A-EL].)
		No	Go to Step 4.
2	**PERFORM ON-BOARD DIAGNOSTIC TEST TO SPECIFY MALFUNCTIONING PART** • Perform the on-board diagnostic test. (See ON-BOARD DIAGNOSTIC TEST MODE [TCM (CW6A-EL)].) • Are any DTCs present?	Yes	DTC P1738:00 is displayed: • Replace the automatic transaxle. (See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [CW6A-EL].) DTC other than P1738:00 is displayed: • Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (CW6A-EL)].)
		No	Go to the next step.
3	**DRIVE VEHICLE AND VERIFY DTCs** • Stop the engine. • Drive the vehicle for **5 min or more** after the engine restarts. • Perform the DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (CW6A-EL)].) • Are any DTCs present?	Yes	DTC P1738:00 is displayed: • Replace the automatic transaxle. (See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [CW6A-EL].) DTC other than P1738:00 is displayed: • Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (CW6A-EL)].)
		No	No DTCs are displayed: • DTC troubleshooting completed.
4	**PERFORM ON-BOARD DIAGNOSTIC TEST** • Perform the on-board diagnostic test. (See ON-BOARD DIAGNOSTIC TEST MODE [TCM (CW6A-EL)].) • Are any DTCs present?	Yes	DTC P1738:00 is displayed: • Replace the automatic transaxle. (See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [CW6A-EL].) DTC other than P1738:00 is displayed: • Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (CW6A-EL)].)
		No	Go to the next step.
5	**DRIVE VEHICLE AND VERIFY DTCs** • Stop the engine. • Drive the vehicle for **5 min or more** after the engine restarts. • Perform the DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (CW6A-EL)].) • Are any DTCs present?	Yes	DTC P1738:00 is displayed: • Replace the automatic transaxle. (See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [CW6A-EL].) DTC other than P1738:00 is displayed: • Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (CW6A-EL)].)
		No	Replace the control valve body. (See CONTROL VALVE BODY REMOVAL/INSTALLATION [CW6A-EL].)