## DTC P1784:00 [TCM (CW6A-EL)]

id0502p4905200

| | |
|---|---|
| **DTC P1784:00** | **Hi cut valve stuck off/R-3-5 cut valve stuck on** |
| **DETECTION CONDITION** | • Under the following conditions, hi cut valve stuck-off or R-3-5 cut valve stuck-on detected by combination of gear ratio malfunction and oil pressure switch pattern malfunction:<br>— Engine is running.<br>— ATF temperature is **20 °C {68 °F} or more**.<br>— There is no difference between vehicle speed signal from ABS HU/CM (with ABS)/DSC HU/CM (with DSC) and output shaft speed sensor signal.<br>— Turbine/input shaft speed sensor and output shaft speed sensor DTC is not recorded. |
| **FAIL-SAFE FUNCTION** | • Inhibits malfunctioning gear.<br>• Limits engine torque.<br>• Inhibits learning control.<br>• Inhibits i-stop control. |
| **POSSIBLE CAUSE** | • ATF is less than specified value<br>• Hi cut valve malfunction<br>• R-3-5 cut valve malfunction<br>• Clutch burnt |
| **SYSTEM WIRING DIAGRAM** | Not applicable |

### Diagnostic procedure

| STEP | INSPECTION | | ACTION |
|---|---|---|---|
| 1 | **VERIFY RELATED SERVICE INFORMATION AVAILABILITY**<br>• Verify related Service Information availability.<br>• Is any related Service Information available? | Yes | Perform repair or diagnosis according to the available Service Information.<br>• If the vehicle is not repaired, go to the next step. |
| | | No | Go to the next step. |
| 2 | **INSPECT ATF LEVEL**<br>• Inspect the ATF level.<br>(See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [CW6A-EL].)<br>• Is there any malfunction? | Yes | Adjust the ATF level to the specification, then go to the next step.<br>(See AUTOMATIC TRANSAXLE FLUID (ATF) ADJUSTMENT [CW6A-EL].) |
| | | No | Replace the automatic transaxle.<br>(See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [CW6A-EL].) |
| 3 | **PERFORM STALL TEST TO VERIFY DTCs**<br>• Clear the DTC using the M-MDS.<br>(See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (CW6A-EL)].)<br>• Perform the stall test in the reverse (R) position.<br>(See MECHANICAL SYSTEM TEST [CW6A-EL].)<br>• Perform the DTC inspection using the M-MDS.<br>(See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (CW6A-EL)].)<br>• Are any DTCs present? | Yes | Replace the automatic transaxle.<br>(See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [CW6A-EL].) |
| | | No | Go to the next step. |
| 4 | **PERFORM ON-BOARD DIAGNOSTIC TEST**<br>• Perform the on-board diagnostic test.<br>(See ON-BOARD DIAGNOSTIC TEST MODE [TCM (CW6A-EL)].)<br>• Are any DTCs present? | Yes | Replace the automatic transaxle.<br>(See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [CW6A-EL].) |
| | | No | Drive the vehicle for **10 min or more**.<br>DTCs are displayed:<br>• Replace the automatic transaxle.<br>(See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [CW6A-EL].)<br>No DTCs are displayed:<br>• DTC troubleshooting completed. |