DTC U0115:00 [TCM (CW6A-EL)]

id0502p4908100

DTC U0115:00	**Communication error to PCM (local CAN between TCM and PCM)**
DETECTION CONDITION	• Under the following condition, the TCM cannot receive the signal from PCM (local CAN between TCM and PCM): — Battery voltage is **10 V or more**.
FAIL-SAFE FUNCTION	• Set to TCC control. • Inhibits learning control. • Inhibits manual mode. • Inhibits i-stop control. • Inhibits AAS. • Inhibits 5GR and 6GR. • Inhibits shift down when the accelerator pedal is depressed.
POSSIBLE CAUSE	• PCM DTC is stored. • PCM malfunction • TCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**RECORD VEHICLE STATUS WHEN DTC WAS DETECTED TO UTILIZE WITH REPEATABILITY VERIFICATION** **Note** • Recording can be facilitated using the screen capture of the PC function. • Record the freeze frame data/snap shot data.	—	Go to the next step.
2	**VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	**VERIFY PCM DTC** • Perform the PCM DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
		No	PCM can be considered the cause. • Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
4	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Clear the DTC using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (CW6A-EL)].) • Perform the following procedure to ensure that the DTC has been resolved: — Switch the ignition ON (engine off or on). • Perform the DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (CW6A-EL)].) • Is the same DTC present?	Yes	Replace the control valve body, then go to the next step. (See CONTROL VALVE BODY REMOVAL/INSTALLATION [CW6A-EL].)
		No	Go to the next step.
5	**VERIFY NO DTC IS PRESENT** • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (CW6A-EL)].)
		No	DTC troubleshooting completed.