ON-BOARD DIAGNOSTIC SYSTEM MALFUNCTION INDICATION FUNCTION [TCM (EW6A-EL)]

id0502p7280400

Purpose/Function

- The on-board diagnostic system malfunction indication function notifies the driver of a transaxle malfunction.
- The malfunction indication function notifies the driver of a transaxle malfunction by illuminating the check engine light and automatic transaxle warning light.

Construction/Operation

- The check engine light and automatic transaxle warning light are equipped in the instrument cluster.
- For vehicles with center display, a warning message in the center display is displayed when check engine light and automatic transaxle warning light are Illuminated. For the message content and verification method, refer to the CENTER DISPLAY. (See CENTER DISPLAY [WITH CENTER DISPLAY].)

Check engine light	
Automatic transaxle warning light	AT