DTC P0500:00 [TCM (EW6A-EL)]

id0502p7321400

DTC P0500:00	Vehicle speed signal circuit malfunction
DETECTION CONDITION	• Under the following conditions, the vehicle speed signal input from DSC HU/CM is incorrect: — Engine is running. — The vehicle is driven in D position or R position. — Output shaft speed sensor related DTC is not recorded — There is correlation between output shaft speed sensor speed and turbine/input shaft speed sensor speed.
FAIL-SAFE FUNCTION	• Inhibits learning control. • Inhibits neutral idle control. • Inhibits i-stop control. • Inhibits AAS.
POSSIBLE CAUSE	• DSC HU/CM DTC is stored. — ABS wheel-speed sensor malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**RECORD VEHICLE STATUS WHEN DTC WAS DETECTED TO UTILIZE WITH REPEATABILITY VERIFICATION** **Note** • Recording can be facilitated using the screen capture of the PC function. • Record the freeze frame data/snap shot data.	—	Go to the next step.
2	**VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	**VERIFY STORED DTC IN DSC HU/CM** • Perform the DSC HU/CM DTC inspection using the M-MDS. (See DTC INSPECTION [DSC HU/CM].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC INSPECTION [DSC HU/CM].)
		No	Go to the next step.
4	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Clear the DTC using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (EW6A-EL)].) • Perform the following procedure to ensure that the DTC has been resolved: 1. Drive the vehicle for **10 s or more** under the following conditions: • Battery voltage: **8 V or more** • Vehicle speed: **45 km/h {28 mph} or more** • Perform the DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (EW6A-EL)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (EW6A-EL)].)
		No	DTC troubleshooting completed.