## DTC P0712:00 [TCM (EW6A-EL)]

id0502p7817400

| | |
|---|---|
| **DTC P0712:00** | **TFT sensor circuit low input** |
| **DETECTION CONDITION** | • Under the following condition, the TFT sensor voltage is **0.12 V or less** for **5 s**:<br>— Battery voltage is **8 V or more**. |
| **FAIL-SAFE FUNCTION** | • Inhibits learning control.<br>• Inhibits neutral idle control.<br>• Inhibits i-stop control. |
| **POSSIBLE CAUSE** | • TFT sensor malfunction |
| **SYSTEM WIRING DIAGRAM** | Not applicable |

### Diagnostic procedure

| STEP | INSPECTION | | ACTION |
|---|---|---|---|
| 1 | **RECORD VEHICLE STATUS WHEN DTC WAS DETECTED TO UTILIZE WITH REPEATABILITY VERIFICATION**<br><br>**Note**<br>• Recording can be facilitated using the screen capture of the PC function.<br><br>• Record the freeze frame data/snap shot data. | — | Go to the next step. |
| 2 | **VERIFY RELATED SERVICE INFORMATION AVAILABILITY**<br>• Verify related Service Information availability.<br>• Is any related Service Information available? | Yes | Perform repair or diagnosis according to the available Service Information.<br>• If the vehicle is not repaired, replace the coupler component.<br>(See COUPLER COMPONENT REMOVAL/ INSTALLATION [EW6A-EL].)<br>Go to the next step. |
| | | No | Replace the coupler component, then go to the next step.<br>(See COUPLER COMPONENT REMOVAL/ INSTALLATION [EW6A-EL].) |
| 3 | **VERIFY DTC TROUBLESHOOTING COMPLETED**<br>• Clear the DTC using the M-MDS.<br>(See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (EW6A-EL)].)<br>• Perform the following procedure to ensure that the DTC has been resolved:<br>1. Switch the ignition ON (engine off or on) and wait for **5 s or more**.<br>• Perform the DTC inspection using the M-MDS.<br>(See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (EW6A-EL)].)<br>• Are any DTCs present? | Yes | Go to the applicable DTC inspection.<br>(See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (EW6A-EL)].) |
| | | No | DTC troubleshooting completed. |