DTC P0757:00 [TCM (EW6A-EL)]

id0502p7819000

DTC P0757:00	**Shift solenoid No.2 stuck on**
DETECTION CONDITION	• Under the following conditions, shift solenoid No.2 stuck-on detected by combination of gear ratio malfunction and oil pressure switch pattern malfunction: — Engine is running. — ATF temperature is **20 °C {68 °F} or more**. — There is no difference between vehicle speed signal from DSC HU/CM and output shaft speed sensor signal. — Turbine/input shaft speed sensor and output shaft speed sensor DTC is not recorded.
FAIL-SAFE FUNCTION	• Inhibits malfunctioning gear. • Limits engine torque. • Inhibits learning control. • Inhibits manual mode. • Inhibits neutral idle control. • Inhibits i-stop control. • Inhibits AAS.
POSSIBLE CAUSE	• Shift solenoid No.2 malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**VERIFY DTC OUTPUT STATUS** • Is the DTC P1738:00 also present?	Yes	Go to the applicable DTC inspection. (See DTC P1738:00 [TCM (EW6A-EL)].)
		No	Go to the next step.
2	**RECORD VEHICLE STATUS WHEN DTC WAS DETECTED TO UTILIZE WITH REPEATABILITY VERIFICATION** **Note** • Recording can be facilitated using the screen capture of the PC function. • Record the freeze frame data/snap shot data.	—	Go to the next step.
3	**VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
4	**PERFORM ON-BOARD DIAGNOSTIC TEST** • Perform the following procedure to ensure that the DTC has been resolved: 1. Start the engine. 2. Verify that the ATF temperature is **55 °C {131 °F} or more**. • Perform the on-board diagnostic test. (See ON-BOARD DIAGNOSTIC TEST MODE [TCM (EW6A-EL)].) • Is the DTC P0757:00 present?	Yes	Replace the control valve body, then go to the next step. (See CONTROL VALVE BODY REMOVAL/INSTALLATION [EW6A-EL])
		No	No DTCs are displayed: • Drive the vehicle to check it, and if there is no problem then the DTC troubleshooting is complete. If a DTC other than the one indicated on the left is displayed: • Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (EW6A-EL)])
5	**RE-PERFORM ON-BOARD DIAGNOSTIC TEST** • Perform the following procedure to ensure that the DTC has been resolved: 1. Start the engine. 2. Verify that the ATF temperature is **55 °C {131 °F} or more**. • Perform the on-board diagnostic test. (See ON-BOARD DIAGNOSTIC TEST MODE [TCM (EW6A-EL)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (EW6A-EL)].)
		No	DTC troubleshooting completed.