DTC P0722:00 [TCM (EW6A-EL)]

id0502p7821500

DTC P0722:00	**Open circuit in output shaft speed sensor circuit**
DETECTION CONDITION	• Under the following conditions, the output shaft speed sensor signal is not input: — Engine is running. — Vehicle speed signal related DTC is not recorded. — The vehicle is driven at the specified speed or more. — There is no difference between vehicle speed signal from DSC HU/CM and output shaft speed sensor signal. — DTC U0121:00 is not recorded.
FAIL-SAFE FUNCTION	• Inhibits learning control. • Inhibits manual mode. • Inhibits neutral idle control. • Inhibits i-stop control. • Inhibits AAS.
POSSIBLE CAUSE	• Output shaft speed sensor malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**RECORD VEHICLE STATUS WHEN DTC WAS DETECTED TO UTILIZE WITH REPEATABILITY VERIFICATION** **Note** • Recording can be facilitated using the screen capture of the PC function. • Record the freeze frame data/snap shot data.	—	Go to the next step.
2	**VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, replace the control valve body. (See CONTROL VALVE BODY REMOVAL/INSTALLATION [EW6A-EL].) Go to the next step.
		No	Replace the control valve body, then go to the next step. (See CONTROL VALVE BODY REMOVAL/INSTALLATION [EW6A-EL].)
3	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Clear the DTC using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (EW6A-EL)].) • Perform the following procedure to ensure that the DTC has been resolved: 1. Drive the vehicle for **1 s or more** under the following condition: • Vehicle speed: **16 km/h {9.9 mph} or more** • Perform the DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (EW6A-EL)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (EW6A-EL)].)
		No	DTC troubleshooting completed.