DTC P0721:00 [TCM (EW6A-EL)]

id0502p7904100

DTC P0721:00	**Output shaft speed sensor/sensor output range malfunction**
DETECTION CONDITION	• Under the following condition, the output shaft speed is **13,560 rpm or more** in forward or **2,000 rpm or more** in reverse for a continuous **1 s**: — Battery voltage is **8 V or more**.
FAIL-SAFE FUNCTION	• Inhibits learning control. • Inhibits manual mode. • Inhibits neutral idle control. • Inhibits i-stop control. • Inhibits AAS.
POSSIBLE CAUSE	• Output shaft speed sensor malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**VERIFY DSC HU/CM DTC** • Perform the DSC HU/CM DTC inspection using the M-MDS. (See DTC INSPECTION [DSC HU/CM].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC INSPECTION [DSC HU/CM].)
		No	Go to the next step.
2	**VERIFY INSTRUMENT CLUSTER REPAIR HISTORY** • Does the instrument cluster have a record of replacement?	Yes	Perform the instrument cluster configuration, then go to Step 6. (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).)
		No	Go to the next step.
3	**VERIFY AUTOMATIC TRANSAXLE REPAIR HISTORY** • Does the automatic transaxle (with control valve body) have a record of replacement?	Yes	Perform the TCM configuration. (See TCM CONFIGURATION [EW6A-EL].)
		No	Go to the next step.
4	**RECORD VEHICLE STATUS WHEN DTC WAS DETECTED TO UTILIZE WITH REPEATABILITY VERIFICATION** **Note** • Recording can be facilitated using the screen capture of the PC function. • Record the freeze frame data/snap shot data.	—	Go to the next step.
5	**VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, replace the control valve body. (See CONTROL VALVE BODY REMOVAL/INSTALLATION [EW6A-EL].) Go to the next step.
		No	Replace the control valve body, then go to the next step. (See CONTROL VALVE BODY REMOVAL/INSTALLATION [EW6A-EL].)

STEP	INSPECTION		ACTION
6	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Clear the DTC using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (EW6A-EL)].) • Perform the following procedure to ensure that the DTC has been resolved: 1. Drive the vehicle for **1 s or more** under the following condition: • Vehicle speed: **30 km/h {19 mph} or more** • Perform the DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (EW6A-EL)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (EW6A-EL)].)
		No	DTC troubleshooting completed.