## DTC P0746:00 [TCM (EW6A-EL)]

id0502p7904200

| DTC P0746:00 | **Pressure control solenoid stuck off** |
|---|---|
| **DETECTION CONDITION** | • Under the following conditions, pressure control solenoid stuck-off detected by combination of gear ratio malfunction and oil pressure switch pattern malfunction:<br>— Engine is running.<br>— ATF temperature is **20 °C {68 °F} or more**.<br>— There is no difference between vehicle speed signal from DSC HU/CM and output shaft speed sensor signal.<br>— Turbine/input shaft speed sensor and output shaft speed sensor DTC is not recorded. |
| **FAIL-SAFE FUNCTION** | • Inhibits malfunctioning gear.<br>• Limits engine torque.<br>• Inhibits learning control.<br>• Inhibits manual mode.<br>• Inhibits neutral idle control.<br>• Inhibits i-stop control.<br>• Inhibits AAS. |
| **POSSIBLE CAUSE** | • ATF is less than specified value<br>• Pressure control solenoid malfunction |
| **SYSTEM WIRING DIAGRAM** | Not applicable |

### Diagnostic procedure

| STEP | INSPECTION | | ACTION |
|---|---|---|---|
| 1 | **VERIFY DTC OUTPUT STATUS**<br>• Is the DTC P1738:00 also present? | Yes | Go to the applicable DTC inspection.<br>(See DTC P1738:00 [TCM (EW6A-EL)].) |
| | | No | Go to the next step. |
| 2 | **RECORD VEHICLE STATUS WHEN DTC WAS DETECTED TO UTILIZE WITH REPEATABILITY VERIFICATION**<br><br>**Note**<br>• Recording can be facilitated using the screen capture of the PC function.<br><br>• Record the freeze frame data/snap shot data. | — | Go to the next step. |
| 3 | **VERIFY RELATED SERVICE INFORMATION AVAILABILITY**<br>• Verify related Service Information availability.<br>• Is any related Service Information available? | Yes | Perform repair or diagnosis according to the available Service Information.<br>• If the vehicle is not repaired, go to the next step. |
| | | No | Go to the next step. |
| 4 | **INSPECT ATF LEVEL**<br>• Inspect the ATF level.<br>(See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [EW6A-EL].)<br>• Is there any malfunction? | Yes | Adjust the ATF level to the specification, then go to the next step.<br>(See AUTOMATIC TRANSAXLE FLUID (ATF) ADJUSTMENT [EW6A-EL].) |
| | | No | Replace the control valve body, then go to the next step.<br>(See CONTROL VALVE BODY REMOVAL/INSTALLATION [EW6A-EL].) |
| 5 | **PERFORM ON-BOARD DIAGNOSTIC TEST**<br>• Perform the following procedure to ensure that the DTC has been resolved:<br>1. Start the engine.<br>2. Verify that the ATF temperature is **55 °C {131 °F} or more**.<br>• Perform the on-board diagnostic test.<br>(See ON-BOARD DIAGNOSTIC TEST MODE [TCM (EW6A-EL)].)<br>• Are any DTCs present? | Yes | Go to the applicable DTC inspection.<br>(See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (EW6A-EL)].) |
| | | No | Drive the vehicle to check it, and if there is no problem then the DTC troubleshooting is complete. |