VEHICLE MOVES IN P POSITION, OR PARKING GEAR DOES NOT DISENGAGE WHEN P IS DISENGAGED [CW6A-EL]

id050321100600

TROUBLESHOOTING ITEM	**Vehicle moves in P position, or parking gear does not disengage when P is disengaged**
DESCRIPTION	• Vehicle rolls when on a downward slope in P position. • Vehicle does not move in D, M and R position when accelerator pedal is depressed, and engine remains in stalled condition.
POSSIBLE CAUSE	1. Parking mechanism malfunction

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**INSPECT PARKING MECHANISM FOR MALFUNCTION** • When the vehicle is stopped on a flat, level road and the engine is off, does the vehicle move when pushed? (In D, N or R position with the brake pedal released.)	Yes	Symptom troubleshooting is completed.
		No	Replace the parking mechanism. (See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [CW6A-EL].)