NOISE OCCURS AT IDLE WHEN VEHICLE IS STOPPED IN ALL POSITIONS [CW6A-EL]

id050321102300

TROUBLESHOOTING ITEM	**Noise occurs at idle when vehicle is stopped in all positions**
DESCRIPTION	• Transaxle is noisy in all positions when vehicle idling.
POSSIBLE CAUSE	1. Engine control system malfunction 2. Automatic transaxle internal parts malfunction — Oil pump malfunction — Torque converter internal parts malfunction

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**VERIFY IF MALFUNCTION CAUSE IS ENGINE CONTROL SYSTEM OR TORQUE CONVERTER** • Inspect the engine condition. • Is there any malfunction?	Yes	Go to the appropriate symptom troubleshooting. (See SYMPTOM DIAGNOSTIC INDEX [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
		No	Replace the automatic transaxle. (See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [CW6A-EL].)