NOISE OCCURS AT IDLE WHEN VEHICLE IS STOPPED IN D, M OR R POSITION [CW6A-EL]

id050321102400

TROUBLESHOOTING ITEM	**Noise occurs at idle when vehicle is stopped in D, M or R position**
DESCRIPTION	• Transaxle is noisy in driving positions when vehicle is idling.
POSSIBLE CAUSE	1. Engine control system malfunction 2. Automatic transaxle internal parts malfunction — Torque converter internal parts malfunction

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**VERIFY IF MALFUNCTION CAUSE IS ENGINE CONTROL SYSTEM OR TORQUE CONVERTER** • Inspect the engine condition. • Is there any malfunction?	Yes	Go to the appropriate symptom troubleshooting. (See SYMPTOM DIAGNOSTIC INDEX [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
		No	Replace the automatic transaxle. (See AUTOMATIC TRANSAXLE REMOVAL/INSTALLATION [CW6A-EL].)