SYMPTOM TROUBLESHOOTING ITEM TABLE [EW6A-EL]

id050322100300

- Use the chart below to verify the symptoms of the trouble in order to diagnose the appropriate area.

Note

- When driving on high-altitude roads, the TCM determines that the driving mode is the AAS mode, and may change to a different shift timing from the normal timing.

Troubleshooting item	Description	Page
Vehicle does not move in D, M or R position	• Vehicle does not move when accelerator pedal is depressed. • The engine revs up but the vehicle does not move even though the accelerator pedal is depressed. • Tires are locked and do not move even though the accelerator pedal is depressed.	(See VEHICLE DOES NOT MOVE IN D, M OR R POSITION [EW6A-EL].)
Vehicle moves in P position, or parking gear does not disengage when P is disengaged	• Vehicle rolls when on a downward slope in P position. • Vehicle does not move in D, M and R position when accelerator pedal is depressed, and engine remains in stalled condition.	(See VEHICLE MOVES IN P POSITION, OR PARKING GEAR DOES NOT DISENGAGE WHEN P IS DISENGAGED [EW6A-EL].)
Excessive creep	• Vehicle accelerates in D and R position when accelerator pedal is not depressed.	(See EXCESSIVE CREEP [EW6A-EL].)
No creep at all	• Vehicle does not move in D, M or R position when idling on flat paved road.	(See NO CREEP AT ALL [EW6A-EL].)
Low maximum speed and poor acceleration	• Vehicle acceleration is poor at start. • Delayed acceleration when accelerator pedal is depressed while driving.	(See LOW MAXIMUM SPEED AND POOR ACCELERATION [EW6A-EL].)
No shifting	• Single shift position only. • Sometimes shifts correctly.	(See NO SHIFTING [EW6A-EL].)
Does not shift to 5GR or 6GR	• Vehicle does not upshift from 4GR to 5GR or 5GR to 6GR even though vehicle speed is increased. • At a vehicle speed range where the transaxle should shift up to 5GR and 6GR gears in D position based on the shift pattern, the transaxle does not shift to 5GR and 6GR gears by gradually releasing the accelerator pedal.	(See DOES NOT SHIFT TO 5GR OR 6GR [EW6A-EL].)
Abnormal shifting	• Shifts incorrectly (incorrect shift pattern).	(See ABNORMAL SHIFTING [EW6A-EL].)
Frequent shifting	• Downshifting occurs suddenly even when accelerator pedal is depressed slightly in D position.	(See FREQUENT SHIFTING [EW6A-EL].)
Shift point is high or low	• Shift point considerably different from shift point. • Shift delays when accelerating. • Shift occurs suddenly when accelerating and engine speed does not increase.	(See SHIFT POINT IS HIGH OR LOW [EW6A-EL].)
No kickdown	• Does not downshift when accelerator pedal is fully depressed within kickdown range.	(See NO KICKDOWN [EW6A-EL].)
Engine flares up or slips when upshifting or downshifting	• When accelerator pedal is depressed, engine speed increases normally but vehicle speed increases slowly. • When accelerator pedal is depressed while driving, engine speed increases but vehicle speed does not.	(See ENGINE FLARES UP OR SLIPS WHEN UPSHIFTING OR DOWNSHIFTING [EW6A-EL].)
Judder upon torque converter clutch (TCC) operation	• Vehicle jolts when TCC is engaged.	(See JUDDER UPON TORQUE CONVERTER CLUTCH (TCC) OPERATION [EW6A-EL].)
Excessive shift shock from N to D or N to R position	• Strong shock is felt when shifting from N to D or N to R position at idle.	(See EXCESSIVE SHIFT SHOCK FROM N TO D OR N TO R POSITION [EW6A-EL].)

Troubleshooting item	Description	Page
Slow engaging after operating selector lever from N to D position	• When depressing the accelerator pedal just after operating the selector lever from N to D position with the ATF temperature at **60 °C {140 °F} or more**, it takes **3 s or more** to engage. • Malfunction symptom only occurs once when accelerating from a standstill. • Engagement after operating the selector lever from N to R position is normal.	(See SLOW ENGAGING AFTER OPERATING SELECTOR LEVER FROM N TO D POSITION [EW6A-EL].)
Excessive shift shock is felt when upshifting and downshifting	• Excessive shift shock is felt when depressing accelerator pedal to accelerate at upshifting. • During cruising, excessive shift shock is felt when depressing accelerator pedal at downshifting.	(See EXCESSIVE SHIFT SHOCK IS FELT WHEN UPSHIFTING AND DOWNSHIFTING [EW6A-EL].)
Excessive shift shock on torque converter clutch (TCC)	• Strong shock is felt when TCC is engaged.	(See EXCESSIVE SHIFT SHOCK ON TORQUE CONVERTER CLUTCH (TCC) [EW6A-EL].)
Noise occurs at idle when vehicle is stopped in all positions	• Transaxle is noisy in all positions when vehicle idling.	(See NOISE OCCURS AT IDLE WHEN VEHICLE IS STOPPED IN ALL POSITIONS [EW6A-EL].)
Noise occurs at idle when vehicle is stopped in D, M or R position	• Transaxle is noisy in driving positions when vehicle is idling.	(See NOISE OCCURS AT IDLE WHEN VEHICLE IS STOPPED IN D, M OR R POSITION [EW6A-EL].)
Transaxle overheats	• Burnt smell emitted from the transaxle. • Smoke is emitted from the transaxle.	(See TRANSAXLE OVERHEATS [EW6A-EL].)
Engine stalls when shifted to D, M or R position	• Engine stalls when shifting from N or P position to D, M or R position at idle.	(See ENGINE STALLS WHEN SHIFTED TO D, M OR R POSITION [EW6A-EL].)
Starter does not work	• Starter does not work even when in P or N position.	(See STARTER DOES NOT WORK [EW6A-EL].)
Gear position indication does not illuminate in M position	• Gear position indication in instrument cluster does not illuminate in M position with the ignition switched ON (engine off or on).	(See GEAR POSITION INDICATION DOES NOT ILLUMINATE IN M POSITION [EW6A-EL].)
Gear position indication illuminates in P, R, N and D positions	• Gear position indication in instrument cluster illuminates in P, R, N and D positions with the ignition switched ON (engine off or on).	(See GEAR POSITION INDICATION ILLUMINATES IN P, R, N AND D POSITIONS [EW6A-EL].)
Manual shift mode indication does not illuminate in M position/Manual shift mode indication illuminates in D position	• Manual shift mode indication in instrument cluster does not illuminate in M position or manual shift mode indication in instrument cluster in P, R, N and D positions with the ignition switched ON (engine off or on).	(See MANUAL SHIFT MODE INDICATION DOES NOT ILLUMINATE IN M POSITION/ MANUAL SHIFT MODE INDICATION ILLUMINATES IN D POSITION [EW6A-EL].)
ATF seeping from automatic transaxle	• ATF is seeping from the automatic transaxle case. • Foreign matter mixed with ATF is in the automatic transaxle case.	(See ATF SEEPING FROM AUTOMATIC TRANSAXLE [EW6A-EL].)