1. Wiring harness between TCM terminal J and PCM terminal 2N malfunction
2. Wiring harness between TCM terminal J and start stop unit terminal 1F malfunction
3.