GEAR POSITION INDICATION DOES NOT ILLUMINATE IN M POSITION [EW6A-EL]

id050322113400

TROUBLESHOOTING ITEM	**Gear position indication does not illuminate in M position**
DESCRIPTION	• Gear position indication in instrument cluster does not illuminate in M position with the ignition switched ON (engine off or on).
POSSIBLE CAUSE	1. Instrument cluster malfunction **Note** • When the ATF temperature is **132 °C {270 °F} or more**, gear fixing is inhibited, the gear position indication is turned off, and the control is changed to the automatic shift control.

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**INSPECT INSTRUMENT CLUSTER FOR MALFUNCTION** • Inspect the instrument cluster. (See INSTRUMENT CLUSTER INSPECTION.) • Is there any malfunction?	Yes	Replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)
		No	Symptom troubleshooting is completed.