GEAR POSITION INDICATION ILLUMINATES IN P, R, N AND D POSITIONS [EW6A-EL]

id050322113500

TROUBLESHOOTING ITEM	**Gear position indication illuminates in P, R, N and D positions**
DESCRIPTION	• Gear position indication in instrument cluster illuminates in P, R, N and D positions with the ignition switched ON (engine off or on).
POSSIBLE CAUSE	1. Instrument cluster malfunction

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**INSPECT INSTRUMENT CLUSTER FOR MALFUNCTION** • Inspect the instrument cluster. (See INSTRUMENT CLUSTER INSPECTION.) • Is there any malfunction?	Yes	Replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)
		No	Symptom troubleshooting is completed.