SYMPTOM TROUBLESHOOTING ITEM TABLE [F66M-R]

id050334100300

- Use the chart below to verify the symptoms of the trouble in order to diagnose the appropriate area.

Malfunction symptom	Page
Vehicle body vibrates during idling or while driving	(See VEHICLE BODY OR CLUTCH PEDAL VIBRATES/SHIFT OPERATION DIFFICULTY/NOISE HEARD [F66M-R].)
Clutch pedal vibrates	
Shift operation is difficult because clutch does not fully release	
Teeth grinding noise is heard	
Booming noise is heard	