CLUTCH STROKE SENSOR REMOVAL/INSTALLATION [F65M-R]

id0510q1156900

Note
- The clutch stroke sensor is equipped only on vehicles with i-stop.
- The clutch stroke sensor is built into the clutch master cylinder.

1. Replace the clutch master cylinder. (See CLUTCH MASTER CYLINDER REMOVAL/INSTALLATION [F65M-R].)