
CLUTCH UNIT REMOVAL/INSTALLATION [F65M-R]

id0510q1157200

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/ CONNECTION.)
2. Remove the manual transaxle. (See MANUAL TRANSAXLE REMOVAL/INSTALLATION [F65M-R].)
3. Remove in the order indicated in the table.
4. Install in the reverse order of removal.
5. Add the specified amount of manual transaxle oil. (See MANUAL TRANSAXLE OIL REPLACEMENT [F65M-R].)



am2zzw00014078

1	Boot
2	Clutch release fork
3	Clutch release collar
4	Pivot pin


5	Clutch cover (See Clutch Cover and Clutch Disc Removal Note.) (See Clutch Disc and Clutch Cover Installation Note.)

6	Clutch disc (See Clutch Cover and Clutch Disc Removal Note.) (See Clutch Disc and Clutch Cover Installation Note.)
7	Pilot bearing (See Pilot Bearing Removal Note.) (See Pilot Bearing Installation Note .)

8	Plate
9	Flywheel (See Flywheel Removal Note .) (See Flywheel Installation Note.)

Clutch Cover and Clutch Disc Removal Note

1. Hold the clutch unit using the **SSTs (49 SE01 310A, 49 E011 1A0)**.
2. Loosen each bolt one turn at a time in a crisscross pattern until spring tension is released.
3. Remove the clutch cover and disc.




adejjw00010428

Pilot Bearing Removal Note

Note
- The pilot bearing does not need to be removed unless you are replacing it.


1. Use the **SST (49 1285 071)** to remove the pilot bearing.



am3uuw00002082

Flywheel Removal Note

1. Hold the flywheel using the **SST (49 E011 1A0)**.
2. Remove the lock bolts, and remove the plate and the flywheel.
3. Inspect for oil leakage from the crankshaft rear oil seal.
   - If there is any malfunction, replace the crankshaft rear oil seal. (See REAR OIL SEAL REPLACEMENT [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)




adejjw00010429

Flywheel Installation Note

1. Degrease and clean the flywheel.
2. Clean the crankshaft thread holes.
3. Install the flywheel and the plate to the crankshaft, and temporarily tighten a new lock bolts.

4. Hold the flywheel using the **SST (49 E011 1A0)**.
5. Tighten the lock bolts completely in the order shown in the figure in the following 3 steps.

Tightening torque
Step 1: 46—54 N·m {4.7—5.5 kgf·m, 34—39 ft·lbf}
Step 2: 76—84 N·m {7.8—8.5 kgf·m, 57—61 ft·lbf}
Step 3: 108—116 N·m {11.1—11.8 kgf·m, 80—85 ft·lbf}




adejjw00010430

Pilot Bearing Installation Note


1. Install new pilot bearing to the specified position using the following tools.

Tool
Snap-on brand millimeter size bushing driver set (A160M) adapter A160M7 (20—22 mm)
- **Use the adapter with the 20 mm side of the A160M7 (20—22 mm) facing the pilot bearing side.**

Substitution tool
Outer diameter: 21 mm {0.83 in}
Inner diameter: 19 mm {0.75 in}


am3uuw00002083

Specified position
Distance A of pilot bearing from crankshaft end: 1.5—2.5 mm {0.060—0.098 in}




am2zzw00009959

Clutch Disc and Clutch Cover Installation Note


Caution
- **Do not apply grease to the spline end (transaxle side). If excessive grease is applied, clutch-slip may occur.**

1. Apply grease to the spline (engine side) of the clutch disc.




am2zzw00014079

2. Insert the clutch disc into the primary shaft and wipe off the excess grease protruding from the spline.
3. Slide the clutch disc three times in the directions of the arrows shown in the figure to engage to grease.




am2zzw00014080


4. Remove the clutch disc from the primary shaft and wipe off the excess grease protruding from the spline.



am2zzw00014081


5. Verify that grease has been lightly applied to the clutch disc and the spline of the primary shaft.






am2zzw00014082

6. Hold the clutch disc position using the **SST (49 SE01 310A)**.



am3uuw00002087

7. Hold the clutch unit using the **SST (49 E011 1A0)**.




adejjw00010431

8. Using the following procedure, install the clutch disc and clutch cover.
   (1) Temporarily tighten the bolts in the order shown in the figure.
   (2) Tighten the bolts completely in two or three steps in the order shown in the figure and install the clutch disc and cover.

   Tightening torque
   25—33 N·m {2.6—3.3 kgf·m, 19—24 ft·lbf}

9. Remove the **SSTs (49 SE01 310A, 49 E011 1A0)**.



am3uuw00008267