CLUTCH COVER INSPECTION [F65M-R]

id0510q1157400

1. Remove the clutch cover. (See CLUTCH UNIT REMOVAL/INSTALLATION [F65M-R].)