HIGH CLUTCH [CW6A-EL]


id0517l1351300

Purpose/Function

- The high clutch operates in 4GR, 5GR, and 6GR and intermittently operates the rear carrier by drive force from the turbine shaft.
- For the high clutch, a centrifugal balance clutch has been adopted to prevent clutch drag and to assure stabilized piston thrust in all engine speed ranges.


Construction

- The high clutch consists of the following parts shown in the figure.




am2zzn00002202

- The driven plate of the high clutch is engaged with the high clutch drum. The high clutch drum is integrated with the turbine shaft, and when the turbine shaft rotates, the high clutch drum and driven plate rotate as a single unit.




am2zzn00002203

- The drive plate of the high clutch is engaged with the high clutch hub. The high clutch hub is engaged with the rear carrier, and the drive plate, high clutch hub, and rear carrier rotate as a single unit.



am2zzn00002204


- For the high clutch piston, a compact and highly reliable bonded seal piston has been adopted in which the piston and seal are molded together.



am2zzn00002205

Centrifugal balance clutch


- The centrifugal balance clutch is built into the high clutch.
- The centrifugal balance chamber is positioned opposing the clutch chamber for the high clutch. In the centrifugal balance chamber, ATF is constantly charged through a specialized hydraulic circuit.



am2zzn00002206

Operation

- If hydraulic pressure is applied to the high clutch piston, the drive plate and driven plate are pressure coupled and drive force from the turbine shaft is transmitted to the rear planetary carrier. In addition, drive force is also transmitted to the front internal gear through the rear planetary gear.



am2zzn00002207


Centrifugal balance clutch

Clutch pressure not applied

- When the clutch drum rotates, centrifugal force is applied to the remaining ATF in the clutch chamber to push the piston, but centrifugal force is also applied to the ATF in the centrifugal balance chamber to force the piston to move back. As a result, the opposing forces of the clutch and balance chambers are offset and the piston does not move, preventing clutch drag.

Clutch pressure applied

- When clutch pressure is applied to the clutch chamber, the piston, which overcomes the opposing centrifugal hydraulic pressure from the balance chamber and the spring force, is pushed in the direction of clutch engagement and the clutch is engaged. At this time, because the centrifugal hydraulic pressure applied to the clutch pressure in the clutch chamber is offset by the centrifugal hydraulic pressure applied to the balance chamber, the effect of piston thrust by the centrifugal force from the clutch drum rotation is eliminated. As a result, stabilized piston force in all engine speed ranges is assured, thus reducing shift shock.



am3uun00002237