UP SWITCH INSPECTION [CW6A-EL]

id0517l1600500

Continuity Inspection

Note
- The up switch is built into the selector lever component.

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/ CONNECTION.)
2. Perform the following procedure to remove the selector lever knob.

Note
- If the servicing is difficult, release the shift lock manually and shift the selector lever to the N position.