DOWN SWITCH REMOVAL/INSTALLATION [EW6A-EL]

id0517l2112300

Note
- The down switch is built into the selector lever component.

1. If the down switch is replaced, replace the selector lever component. (See AUTOMATIC TRANSAXLE SHIFT MECHANISM REMOVAL/INSTALLATION.)