ROAD TEST [EW6A-EL]

id0517l2118400

Warning
- **When performing a road test, always verify the safety of the surrounding area before performing the test.**

Note
- When performing a road test requiring speeds which exceed the legal speed limit, use a dynamometer.

Road Test Preparation
1. Inspect the engine coolant level. (See ENGINE COOLANT LEVEL INSPECTION [SKYACTIV-D 1.5].)
2. Inspect the engine oil level. (See ENGINE OIL LEVEL INSPECTION [SKYACTIV-D 1.5].)
3. Inspect the ATF level. (See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [EW6A-EL].)
4. Inspect the idle speed. (See ENGINE TUNE-UP [SKYACTIV-D 1.5].)
5. Verify that no DTCs are stored.

D Position Test
1. Perform road test preparations. (See Road Test Preparation.)
2. Warm up the transaxle.
3. Select D position.
4. Inspect the shift point for the D position in normal mode.
   - If there is any malfunction, refer to symptom troubleshooting and verify the malfunction symptom.
   (1) Depress the accelerator pedal and start the vehicle, and verify that the gears shift from 1st to 2nd, 2nd to 3rd, 3rd to 4th, 4th to 5th, and 5th to 6th. In addition, verify that the vehicle speed corresponds to the shift point when shifting.
   (2) Release the accelerator pedal while driving in 6th gear, and verify that the gears shift from 6th to 5th, 5th to 4th, 4th to 3rd, 3rd to 2nd, and 2nd to 1st. In addition, verify that the vehicle speed corresponds to the shift point when shifting.

Note
- When the accelerator pedal is fully released quickly, shifting is not performed according to the shift pattern because the gear being used may be maintained.
- When decelerating by strongly depressing the brake pedal, shifting is not performed according to the shift pattern because the shift-down point may be at high vehicle speed.

   (3) Kickdown while driving in 6th, 5th, 4th, 3rd, and 2nd gears, and verify that the gears shift from 6th to 5th, 5th to 4th, 4th to 3rd, 3rd to 2nd, and 2nd to 1st. In addition, verify that the vehicle speed limit for kickdown corresponds to the shift point.
   (4) Verify that the shift shock is minimal, shifting is smooth and timely, and there is no abnormal noise or slip.
   (5) Verify that the TCC is engaged.

Shift point (Except Thailand)

Position/mode		Accelerator pedal depression amount	Shift	Vehicle speed (km/h {mph})
D	NORMAL	8/8	$D_1 \rightarrow D_2$	39—47 {25—29}
			$D_2 \rightarrow D_3$	68—81 {43—50}
			$D_3 \rightarrow D_4$	95—115 {60.0—71.4}
			$D_4 \rightarrow D_5$	128—156 {79.6—96.9}
			$D_5 \rightarrow D_6$	176—214 {110—132}
		25% (APP)	$D_1 \rightarrow D_2$	16—18 {10—11}
			$D_2 \rightarrow D_3$	27—31 {17—19}
			$D_3 \rightarrow D_4$	38—45 {24—27}
			$D_4 \rightarrow D_5$	55—67 {35—41}
			$D_5 \rightarrow D_6$	69—83 {43—51}
		0/8	$D_6 \rightarrow D_5$	60—72 {38—44}
			$D_5 \rightarrow D_4$	51—61 {32—37}
			$D_4 \rightarrow D_3$	33—39 {21—24}
			$D_3 \rightarrow D_2$	15—17 {9.4—10.0}
			$D_2 \rightarrow D_1$	6.6—8.0 {4.11—4.97}

Shift point (Thailand)

Position/mode		Accelerator pedal depression amount	Shift	Vehicle speed (km/h {mph})
D	NORMAL	8/8	$D_1 \rightarrow D_2$	39—47 {25—29}
			$D_2 \rightarrow D_3$	68—81 {43—50}
			$D_3 \rightarrow D_4$	95—115 {60.0—71.4}
			$D_4 \rightarrow D_5$	128—156 {79.6—96.9}
			$D_5 \rightarrow D_6$	176—214 {110—132}
		25% (APP)	$D_1 \rightarrow D_2$	15—18 {9.4—11.0}
			$D_2 \rightarrow D_3$	24—29 {15—18}
			$D_3 \rightarrow D_4$	35—42 {22—26}
			$D_4 \rightarrow D_5$	49—59 {31—36}
			$D_5 \rightarrow D_6$	60—73 {38—45}
		0/8	$D_6 \rightarrow D_5$	51—61 {32—37}
			$D_5 \rightarrow D_4$	43—51 {27—31}
			$D_4 \rightarrow D_3$	31—36 {20—22}
			$D_3 \rightarrow D_2$	13—15 {8.1—9.3}
			$D_2 \rightarrow D_1$	6.6—8.0 {4.11—4.97}

M Position Test

1. Perform road test preparations. (See Road Test Preparation.)
2. Warm up the transaxle.
3. Select the M position.
4. Inspect the shift point for the M position.
   - If there is any malfunction, refer to symptom troubleshooting and verify the malfunction symptom.
   (1) Perform the shift operation while driving and verify that the gears can be shifted.
   (2) Release the accelerator pedal while driving in 6th gear, and verify that the gears shift from 6th to 5th, 5th to 4th, 4th to 3rd, 3rd to 2nd, and 2nd to 1st. In addition, verify that the vehicle speed corresponds to the shift point when shifting.
   (3) Release the accelerator pedal while driving and verify that the engine braking operates in all gears.
   (4) Verify that the shift shock is minimal, shifting is smooth and timely, and there is no abnormal noise or slip.

Shift point (Except Thailand)

Position/mode	Accelerator pedal depression amount	Shift	Vehicle speed (km/h {mph})
M	0/8	$M_6 \rightarrow M_5$	60—72 {38—44}
		$M_5 \rightarrow M_4$	51—61 {32—37}
		$M_4 \rightarrow M_3$	33—39 {21—24}
		$M_3 \rightarrow M_2$	15—17 {9.4—10.0}
		$M_2 \rightarrow M_1$	6.6—8.0 {4.11—4.97}

Shift point (Thailand)

Position/mode	Accelerator pedal depression amount	Shift	Vehicle speed (km/h {mph})
M	0/8	$M_6 \rightarrow M_5$	51—61 {32—37}
		$M_5 \rightarrow M_4$	43—51 {27—31}
		$M_4 \rightarrow M_3$	31—36 {20—22}
		$M_3 \rightarrow M_2$	13—15 {8.1—9.3}
		$M_2 \rightarrow M_1$	6.6—8.0 {4.11—4.97}

5. Inspect 2nd gear fixed mode.
   (1) While the vehicle is stopped or the vehicle speed is **10 km/h {6.2 mph} or less**, operate the selector lever toward + to shift to 2nd gear.
   (2) Verify that the gear is fixed in 2nd gear.
   (3) Release the accelerator pedal while driving and verify that the engine braking operates.
   (4) Perform the shift operation while driving and verify that the gears can be shifted.

P Position Test

1. Park the vehicle on a gentle slope and shift the selector lever to the P position.
2. Release the brake and verify that the vehicle does not move.
    - If there is any malfunction, inspect the parking mechanism in the transaxle.