R-3-5 BRAKE [EW6A-EL]

id0517l2351400

Purpose/Function

- The R-3-5 brake operates in 3GR, 5GR and in reverse to lock the reduction internal gear against rotation.

Construction

- The R-3-5 brake consists of the following parts shown in the figure.

