2-6 BRAKE [EW6A-EL]

id0517l2351500

Purpose/Function

- The 2-6 brake locks the rear internal gear and reduction planetary carrier while in 2GR and 6GR.

Construction

- The 2-6 brake consists of the following parts shown in the figure.

