TRANSAXLE FLUID TEMPERATURE (TFT) SENSOR [EW6A-EL]


id0517I2360600

Purpose/Function

- The transaxle fluid temperature (TFT) sensor detects the ATF temperature in the oil pan.
- The transaxle fluid temperature (TFT) sensor signal is used for automatic shift control, TCC control, line pressure control, direct electric shift control, learning control, and the on-board diagnostic system.

Construction

- The transaxle fluid temperature (TFT) sensor is integrated with the coupler component and installed to the control valve body.



am3uun00002351

Operation

- The transaxle fluid temperature (TFT) sensor outputs the signal corresponding to the ATF temperature in the oil pan to the TCM.