SHIFT SOLENOID NO.1 [EW6A-EL]

id0517l2361100

Purpose/Function

- Shift solenoid No.1 adjusts the hydraulic pressure in the low clutch circuit based on the current demand from the TCM according to the vehicle conditions.

Construction

- Shi 0 0 6.noid No.1 is installed to the 0 6.no id control valve body.
- Shift so6.noid No.1 is a normal closed-type linear solenoid.