
ENGINE-TRANSAXLE INTEGRATION CONTROL [EW6A-EL]

id0517I2362800

Outline

- The TCM controls engine output torque and reduces transaxle output shaft torque fluctuation during auto shifting, and reduces shock occurring from the vehicle during shifting.


Construction



am6zzn00002705

Operation

- During auto shifting, the TCM sends a torque reduction request signal using the CAN system and temporarily reduces the engine output torque by the PCM fuel injection control. As a result, transaxle output shaft torque fluctuation is reduced during auto shifting by smooth engagement of the clutch.
- In addition, the TCM receives the engine output torque from the PCM via the CAN signal to determine the clutch engagement pressure according to the engine output torque. As a result, the clutch hydraulic control setting accuracy is increased and smooth shift performance is achieved.



atsuzn00000663