CLEARING DTC [EPS CONTROL MODULE]

id060230813100

1. Switch the ignition OFF and wait for 1 min.
2. Connect the M-MDS to the DLC-2.
3. Switch the ignition ON (engine off).
4. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
   (1) Select “Self Test”.
   (2) Select “All CMDTCs”.
5. Verify the DTC according to the directions on the screen.
6. Press the clear button on the DTC screen to clear the DTC.
7. Perform DTC inspection. (See DTC INSPECTION [EPS CONTROL MODULE].)
8. Verify that no DTCs are displayed.