DTC TABLE [EPS CONTROL MODULE]

id060230813200

×: Applicable
—: Not applicable

DTC	Power steering malfunction indicator light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
C1B00:2F	Not illuminate	Steering angle sensor	×	—	C	×	(See DTC C1B00:2F/ C1B00:61/ C1B00:62 [EPS CONTROL MODULE].)
C1B00:54	Illuminates/flashes	Steering angle sensor	×	—	C	×	(See DTC C1B00:54, C1B00:95 [EPS CONTROL MODULE].)
C1B00:61	Illuminates	Steering angle sensor	×	—	C	×	(See DTC C1B00:2F/ C1B00:61/ C1B00:62 [EPS CONTROL MODULE].)
C1B00:62	Illuminates	Steering angle sensor	×	—	C	×	
C1B00:95	Illuminates	Steering angle sensor	×	—	C	×	(See DTC C1B00:54, C1B00:95 [EPS CONTROL MODULE].)
C200B:2F	Illuminates	Torque sensor	×	—	C	×	(See DTC C200B: 2F/C200B:61/ C200B:62/C200C: 2F [EPS CONTROL MODULE].)
C200B:61	Illuminates	Torque sensor	×	—	C	×	
C200B:62	Illuminates	Torque sensor	×	—	C	×	
C200C:2F	Illuminates	Torque sensor	×	—	C	×	
C200D:49	Illuminates	EPS motor	×	—	C	×	(See DTC C200D: 49/U2011:49/ U2011:61 [EPS CONTROL MODULE].)
U0001:88	Not illuminate	CAN communication: module communication error	×	—	C	×	(See DTC U0001:88/ U0100:00/ U0121:00/ U0155:00/ U0214:00 [EPS CONTROL MODULE].)
U0100:00	Illuminates	CAN communication: communication error to PCM	×	—	C	×	
U0121:00	Not illuminate	CAN communication: communication error to DSC HU/CM	×	—	C	×	
U0155:00	Not illuminate	CAN communication: communication error to instrument cluster	×	—	C	×	
U0214:00	Not illuminate	CAN communication: communication error to start stop unit	×	—	C	×	
U0338:00	Not illuminate	CAN communication: signal error from start stop unit	×	—	C	×	(See DTC U0338:00/ U0515:00 [EPS CONTROL MODULE].)

DTC	Power steering malfunction indicator light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
U0401:00	Illuminates	CAN communication: signal error from PCM (engine speed)	×	—	C	×	(See DTC U0401:00 [EPS CONTROL MODULE].)
	Illuminates	CAN communication: signal error from PCM (vehicle speed)	×	—	C	×	
	Not illuminate	CAN communication: signal error from PCM (i-stop condition)	×	—	C	×	
U0415:00	Not illuminate	CAN communication: signal error from DSC HU/CM	×	—	C	×	(See DTC U0415:00 [EPS CONTROL MODULE].)
U0515:00	Not illuminate	CAN communication: signal error from start stop unit	×	—	C	×	(See DTC U0338:00/ U0515:00 [EPS CONTROL MODULE].)
U2011:49	Illuminates	EPS motor	×	—	C	×	(See DTC C200D: 49/U2011:49/ U2011:61 [EPS CONTROL MODULE].)
U2011:61	Illuminates	EPS motor	×	—	C	×	
U2300:54	Not illuminate	EPS configuration	×	—	C	×	(See DTC U2300:54/ U2300:55/ U2300:56 [EPS CONTROL MODULE].)
U2300:55	Illuminates	EPS configuration	×	—	C	×	
U2300:56	Not illuminate	EPS configuration	×	—	C	×	
U3000:05	Illuminates	EPS control module	×	—	C	×	(See DTC U3000:05/ U3000:41/ U3000:43/ U3000:46/ U3000:49/ U3000:61/ U3000:96 [EPS CONTROL MODULE].)
U3000:41	Illuminates	EPS control module	×	—	C	×	
U3000:43	Not illuminate	EPS control module	×	—	C	×	
U3000:46	Illuminates	EPS control module	×	—	C	×	
U3000:49	Illuminates	EPS control module	×	—	C	×	
U3000:61	Illuminates	EPS control module	×	—	C	×	
U3000:96	Illuminates	EPS control module	×	—	C	×	
U3003:16	Illuminates	Battery power supply	×	—	C	×	(See DTC U3003:16 [EPS CONTROL MODULE].)
U3003:17	Illuminates	Battery power supply	×	—	C	×	(See DTC U3003:17 [EPS CONTROL MODULE].)
U3004:49	Illuminates	EPS control module	×	—	C	×	(See DTC U3004:49 [EPS CONTROL MODULE].)

*1 : C: CMDTC self test

Fail-safe function table

DTC	EPS motor current control
C1B00:2F	Control enabled
C1B00:54	Control enabled
C1B00:61	Control disabled
C1B00:62	Control enabled
C1B00:95	Control enabled

DTC	EPS motor current control
C200B:2F	Control disabled
C200B:61	Control disabled
C200B:62	Control disabled
C200C:2F	Control disabled
C200D:49	Control disabled/Control is maintained in the backup control
U0001:88	Control enabled
U0100:00	Control is maintained by gradually changing the controlled vehicle speed and setting it to specified speed
U0121:00	Control enabled
U0155:00	Control enabled
U0214:00	Control enabled
U0338:00	Control enabled
U0401:00	• Engine speed — Control enabled • Vehicle speed — Control is maintained by gradually changing the controlled vehicle speed and setting it to specified speed • i-stop condition — Control enabled
U0415:00	Control enabled
U0515:00	Control enabled
U2011:49	Control disabled/Control is maintained in the backup control
U2011:61	Control disabled
U2300:54	Control enabled
U2300:55	Control enabled
U2300:56	Control enabled
U3000:05	Control disabled
U3000:41	Control disabled
U3000:43	Control enabled
U3000:46	Control disabled
U3000:49	Control disabled
U3000:61	Control disabled
U3000:96	Control disabled
U3003:16	Control is maintained by gradually decreasing the motor control current. However, control is inhibited if the power supply voltage is the specified value of less
U3003:17	Control disabled
U3004:49	Control disabled