DTC U2300:54/U2300:55/U2300:56 [EPS CONTROL MODULE]

id060230813700

DTC	**U2300:54** **U2300:55** **U2300:56**	**EPS configuration**
DETECTION CONDITION		• EPS control module detects configuration data not read or data error
FAIL-SAFE FUNCTION		• U2300:54, U2300:56 — Power steering malfunction indicator light does not Illuminate — EPS motor current control enabled • U2300:55 — Power steering malfunction indicator light Illuminates — EPS motor current control enabled
POSSIBLE CAUSE		• Configuration procedure is not done properly • Correct data cannot be received from instrument cluster
SYSTEM WIRING DIAGRAM		—

Diagnostic Procedure

Step	Inspection		Action
1	**RECORD CONFIGURATION DATA** • Switch the ignition OFF. • Switch the ignition ON (engine off or on), and maintain this condition for **approx. 1 min**. • Switch the ignition OFF, and maintain this condition for **approx. 3 s**. • Switch the ignition ON (engine off or on).		Go to the next step.
2	**VERIFY EPS CONTROL MODULE DTC** • Using the M-MDS, clear the DTC from the EPS control module. (See CLEARING DTC [EPS CONTROL MODULE].) • Using the M-MDS, perform the EPS control module DTC inspection. (See DTC INSPECTION [EPS CONTROL MODULE].) • Is the same DTC present?	Yes	Repeat the inspection from Step1. If the malfunction recurs, go to the next step.
		No	Go to Step5.
3	**VERIFY INSTRUMENT CLUSTER DTC** • Using the M-MDS, perform the instrument cluster DTC inspection. (See DTC INSPECTION [INSTRUMENT CLUSTER].) • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER].) Repair the instrument cluster, then perform the configuration for the instrument cluster. (See INSTRUMENT CLUSTER DISASSEMBLY/ ASSEMBLY.) (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).)
		No	Go to the next step.
4	**VERIFY EPS CONTROL MODULE DTC** • Using the M-MDS, clear the DTC from the EPS control module. (See CLEARING DTC [EPS CONTROL MODULE].) • Using the M-MDS, perform the EPS control module DTC inspection. (See DTC INSPECTION [EPS CONTROL MODULE].) • Is the same DTC present?	Yes	Repeat the inspection from Step1. If the malfunction recurs, replace the steering column, then go to the next step. (See STEERING WHEEL AND COLUMN REMOVAL/ INSTALLATION.)
		No	Go to the next step.
5	**VERIFY NO DTC IS PRESENT** • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [EPS CONTROL MODULE].)
		No	DTC troubleshooting completed.