	• PDS steering malfunction indicator light doeE not Illuminate
POSSIBLE CAUSE	

Repeat the inspection from Step1.