NO.1 POWER ASSIST DIFFERS BETWEEN RIGHT AND LEFT TURNS [ELECTRIC POWER STEERING (EPS)]

id0603a2811400

1	**Power assist differs between right and left turns.**

TROUBLESHOOTING HINTS

- Steering gear and linkage malfunction.
- EPS control module malfunction.
- Poor connection of EPS control module connector, terminal damage.
- The steering wheel angle neutral position learning function has not been operated.

Note

- The steering angle learned by the EPS control module is cleared when **1 min. or more** has elapsed after the battery negative terminal was disconnected.

Diagnostic procedure

STEP	INSPECTION		ACTION
1	• Have DTCs been recorded in the memory? (See DTC INSPECTION [EPS CONTROL MODULE].)	Yes	Perform inspection using the appropriate DTC. (See DTC TABLE [EPS CONTROL MODULE].)
		No	Go to the next step.
2	• Switch the ignition to off and maintain this condition **1 min. or more**. • Switch the ignition ON (engine on). • Drive for **25 sec. or more** in a straight line at **more than 10 km/h {6.2 mph}**. • Is there recurrence of malfunction?	Yes	Go to the next step.
		No	Temporary error occurred while learning steering wheel angle neutral position. There is not malfunction in the EPS system.
3	• Inspect the connection of the EPS control module connector. • Disconnect the EPS control module connector. • Inspect both the EPS control module and wiring harness-side connector for poor connection (such as damage/pulled-out pins, corrosion). • Are all the pins normal?	Yes	Perform wheel alignment inspection. (See WHEEL ALIGNMENT PRE-INSPECTION.) (See FRONT WHEEL ALIGNMENT.) (See REAR WHEEL ALIGNMENT.)
		No	**If poor connection of EPS control module connector:** • Securely connect the EPS control module connector. **If the EPS control module side connector is wrong:** • Replace the steering column. (See STEERING WHEEL AND COLUMN REMOVAL/ INSTALLATION.) **If the wiring harness-side connector is wrong:** • Repair or replace the pins and/or the connector. • Recheck malfunction symptoms, then replace the steering gear and linkage. (See STEERING GEAR AND LINKAGE REMOVAL/ INSTALLATION.)