DTC U2300:54, U2300:55, U2300:56, U2300:64 [FULL-AUTO AIR CONDITIONER]

id0702c1745500

System malfunction location	• U2300:54: Configuration error (data not received) • U2300:55: Configuration error (not configured) • U2300:56: Configuration error (ineffective/non-interchangeable data read) • U2300:64: Configuration error (error value read)
Detection condition	• Climate control unit detects configuration data not record or data error
Fail-safe function	• Sets the configuration value to the fixed value
Possible cause	**Note** • If power from the battery is interrupted, the climate control unit will go into a non-configured state because the memory for the configuration information is erased. • Normally, the configuration is re-performed within **6 s** after the ignition is switched ON (engine off). • After performing the configuration, DTC U2300:55 will be cleared if the ignition is switched ON (engine off) after the ignition is switched off. • Module configuration procedure was not completed properly • Correct data cannot be received from instrument cluster • Climate control unit malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**RECORD CAR CONFIGURATION DATA** • Switch the ignition ON (engine off) and wait for **6 s or more**. • Switch the ignition off. • Switch the ignition ON (engine off).		Go to the next step.
2	**VERIFY THAT SAME DTC IS NOT PRESENT** • Clear the DTCs from the memory. (See CLEARING DTC [FULL-AUTO AIR CONDITIONER].) • Perform the climate control unit DTC inspection using the M-MDS. (See DTC DISPLAY [FULL-AUTO AIR CONDITIONER].) • Are the same DTCs present?	Yes	Repeat the inspection from Step 1. If the malfunction recurs, go to the next step.
		No	Go to Step 5.
3	**INSPECT FOR INSTRUMENT CLUSTER MALFUNCTION** • Switch the ignition off. • Perform the instrument cluster DTC inspection using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER].) After repairing the instrument cluster, perform the instrument cluster configuration. (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).) Then go to the next step.
		No	Go to the next step.
4	**VERIFY THAT SAME DTC IS NOT PRESENT** • Clear the DTCs from the memory. (See CLEARING DTC [FULL-AUTO AIR CONDITIONER].) • Perform the climate control unit DTC inspection using the M-MDS. (See DTC DISPLAY [FULL-AUTO AIR CONDITIONER].) • Are the same DTCs present?	Yes	Repeat the inspection from Step 1. • If the malfunction does not recur, go to the next step. • If the malfunction recurs, replace the climate control unit. (See CLIMATE CONTROL UNIT REMOVAL/ INSTALLATION [FULL-AUTO AIR CONDITIONER].) Go to the next step.
		No	Go to the next step.
5	**VERIFY THAT NO OTHER DTCs ARE PRESENT** • Verify other DTCs displayed. (See DTC DISPLAY [FULL-AUTO AIR CONDITIONER].) • Are any other DTCs output?	Yes	Perform the corresponding DTC inspection. (See DTC TABLE [FULL-AUTO AIR CONDITIONER].)
		No	DTC troubleshooting completed.